

## Before Use

Thank you for purchasing the FrexiousCare Indoor Air Purifier.

FrexiousCare Indoor Air Purifier offers you and your family the best protection against a variety of indoor air pollutants such as PM2.5, bacteria, formaldehyde, and other volatile organic chemicals (VOCs).

Before using the product, please read this operating manual and follow the instructions carefully to prevent any accident.

Start enjoying your brand new air purifier for cleaner and healthier air.

## Warranty and Service

### Scope of Warranty:

- The product must be used according to the instructions in the operating manual;
- The product must be handled properly according to its intended usage;
- The original purchase receipt and registered warranty card must be produced.

The MANN+HUMMEL warranty does not apply if the product is damaged due to accidents, normal wear and tear, or inappropriate usage.

Please refer to the MANN+HUMMEL website at [www.mann-hummel.com](http://www.mann-hummel.com) for more information or assistance. You may also contact the retail outlet where you purchased the product.

## I. Important Information



**Caution:** To prevent accidents or damages to property, please follow the guidelines and instructions below.


-  Do not operate the product or touch the power plug if your hand is wet as you may get an electric shock.
-  Do not wet the product as this may cause short circuits and electric shocks.
-  Keep the product away from flammable substances or fire sources.
-  Do not operate the product if any of the parts, including the power plug, power cord or the purifier body is damaged.  
The damaged parts must be replaced by the manufacturer or authorized service centre in order to avoid hazards.
-  Do not connect the product to the power source if the nominal voltage of the product is different from the local mains voltage as this may result in fire or damage the product.
-  Do not disassemble, repair or alter the product without authorization. Unauthorized disassembly or repair may cause failure and danger; Unauthorized alteration may result in fire or breakdown.
-  Do not use alcohol or solvents to clean the product as it will damage the product or cause electric shocks leading to injuries or fire, etc.
-  Do not bend, drag, twist or put pressure on the power cable. Hold the power plug firmly when disconnecting the power cable from the socket.
-  Do not block the air inlets and outlets of the product. Poor air circulation will affect product performance.
-  Do not insert or throw any object into the air vents of the product.
-  Do not let children play with the product.  
Cleaning and maintenance of the product shall not be performed by children without supervision.
-  Disconnect the product from the power supply first before opening the back cover, installing or replacing the filter components, cleaning or moving the purifier.
-  Unless under supervision by persons responsible for their safety, persons, including children aged 8 years and above, with reduced sensory, mental and physical abilities, or who are not familiar with operating instructions, are not allowed to operate the product.
-  The product is not intended to replace proper indoor ventilation, the use of a fan or extractor hood while cooking, or regular vacuum cleaning of indoor space.
-  The product should always be placed on a flat, level, dry and stable surface.
-  Keep the power cable away from the pathway to prevent people from tripping over the power cable.
-  Do not place or operate the product in areas of wet or high-temperature environmental surroundings, such as kitchen, bathroom or in areas of significant temperature changes to prevent condensation inside the product.
-  Do not place or operate the product near any gas appliances, fireplaces and other heating appliances.
-  Leave a gap of free space of at least 30cm on both sides, behind and above the product to prevent impacting the performance of the purifier.
-  The purifier does not remove carbon monoxide (CO) or radon (Rn) and should not be used in case of accidents involving combustion processes and hazardous chemicals.
-  The product incorporates an earth connection for functional purposes only.
-  Only use the original replacement filter by MANN+HUMMEL that is intended for this product.



**Caution:** Disconnect the purifier from the power source immediately in case of the following scenarios.

-  If the control panel is not working.
-  If the power plug or cord is unusually hot.
-  If there is a burning smell or unusual sounds and vibrations.
-  If there are other anomalies and malfunctions.

## 2. Parts and Control Panel



### 3. Installation Guidelines



**Caution:** Please disconnect the purifier from the power source when installing or replacing the filter.




**Caution:** The filter is NOT washable. Please only purchase FreციousCare original replacement filter to ensure performance and avoid damaging the product.

- I. Please hold onto the purifier.  
Place your fingers in the groove of the back cover and gently pull the back cover outwards to remove it.



2. (i) **When using the purifier for the first time**, please remove the sealed packaging of the filter.



- (ii) **When replacing the filter**, hold the handles of the used filter and remove it from the purifier. Remove and discard all packaging material from the new filter.



3. To insert the filter into the purifier, put the filter into the main casing with the side that has the handles facing outwards.



4. Hold the back cover of the purifier; insert the bottom hooks of the back cover into the bottom slots of the purifier; and then push the back cover against the purifier to reattach the back cover firmly.



## 4. Operating

### 4.1 Switch On/Off

1. Before connecting the purifier to the power source, please make sure that the nominal voltage of the purifier is the same as the local mains voltage.
2. Connect the power plug of the purifier to a power supply socket.

*If the POWER button on the control panel lights up, it indicates that the purifier is on standby.*

3. Touch the POWER button to switch on the purifier:

*The default operating mode is AUTO mode. The mode and fan speed can be adjusted at any time with the MODE and FAN SPEED buttons.*

4. Touch the POWER button to switch off the purifier:

### 4.2 Operating Mode and Fan Speed Settings

1. The default operating mode is AUTO mode when the purifier is switched on.

*In AUTO mode, the fan speed of the purifier is controlled by a programmed sequence. If the room is dark, the purifier will switch to the SLEEP setting automatically, with SILENT fan speed and operating indicator switched off.*

2. Touch the MODE button to select the ANTI-HAZE mode or SILENT mode.

*It is recommended to use the ANTI-HAZE mode when the air is highly polluted and SILENT mode when you need a quiet environment.*

3. Touch the FAN SPEED button to select your desired fan speed.

*Besides the ANTI-HAZE mode and SILENT mode, three other fan speeds can be chosen – LOW speed, MEDIUM speed, and HIGH speed.*


### 4.3 Operating Timer

Touch the TIMER button to set the operating time of the purifier – 1 hour (1h), 4 hours (4h) or 8 hours (8h).

The timer will count down once the operating timer is set and the corresponding time symbol light is on. The purifier will switch off automatically once the operating time reaches the set time, regardless of whether the operating mode or fan speed has been changed during this period.

### 4.4 Filtration Technology

Utilizing MANN+HUMMEL's more than 75 years of filtration expertise, our leading edge separation technology is highly effective against fine dust (PM2.5), formaldehyde, bacteria and other particulate and gaseous pollutants. Our filters use a 3-layer structure that provides pre-filtration, removal of volatile organic compounds (VOCs) and High Performance Filtration. The pre-filter layer removes coarse particles (e.g. hair, dust, pollen); an added layer of highly efficient activated carbon captures gaseous pollutants such as formaldehyde, unpleasant odors and other organic & inorganic contaminants; the High Performance Filtration removes fine particulate matter including PM2.5, smoke, bacteria and other microorganisms.



## 4.5 Filter Replacement Reminder and Reset

The filter has to be replaced when the filter replacement reminder light is on. After changing the filters, please hold the RESET button for 5 seconds until the filter replacement reminder light is off.

## 5. Maintenance



### Caution:

- ❗ Please do not dismantle the product to avoid electric shocks.
- ❗ Please disconnect the power cable when replacing the filter or performing maintenance on the product.
- ❗ Do not use highly flammable agents such as alcohol or other solvents to clean the product.
- ❗ Never immerse the product in any liquid.
- ❗ Ensure that the product is completely dry before securely connecting it to a power source.

### 5.1 Maintenance of Purifier Equipment

If dust accumulates on the surface of the purifier equipment, please wipe away the dust with a soft and dry cloth.

If there are marks on the surface that cannot be removed by a soft and dry cloth, wipe it down with a soft cloth dipped in mild household detergent. Do not use the product until it is completely dry.

Do regularly clean the air outlet vents with a soft and dry cloth to prevent dust from collecting on the inside and outside of the product.



**Caution:** The filter should be replaced when the filter replacement reminder light is on.



**Caution:** Do not try to clean the filter in any way!

## 5.2 Replacement of Filter

FreciousCare Indoor Air Purifier filter is recommended to be replaced after every 6-12 months of use. However, different environmental conditions and frequencies of use can influence the filter's lifetime.

The filter has to be replaced latest when the filter replacement reminder symbol light is on. Please only purchase the FreciousCare original replacement filter to ensure performance and avoid damaging the purifier. Follow the installation guidelines described in Section 3 of the operating manual to replace the filter.

After the filter has been replaced, touch and hold onto the RESET button for 5 seconds until the filter replacement reminder light is off.

## 6. Troubleshooting

If you face problems with the product, please troubleshoot with the following possible solutions. If the purifier still does not operate normally, please contact our after-sales service department.

Issue	Possible Solution
The purifier is not working.	The purifier may not be switched on. Touch the POWER button on the control panel to turn the purifier on.
	Ensure that the plug is securely connected to a power source.
The air quality does not improve, even after long periods in operation.	The purifier may be installed in a position blocked by objects. Change the position of the purifier or remove any obstructing object.
	The filter is not properly installed. Ensure that the filter is properly installed.
	The indoor space that the purifier is placed in is larger than the effective coverage area of the purifier. It will take a longer time to purify the air in a larger room. The maximum coverage area of the purifier is 60 m <sup>2</sup> .
There is unusual sound from the purifier during operation.	The packaging of the filter may not have been removed. Ensure that all the packaging material is removed from the purifier.
The filter replacement reminder light and RESET button are still lit even after the filter has been replaced and the RESET button has been held.	Touch and hold onto the RESET button for a longer time until the lights are turned off.
There is no air coming out of the air vents.	There may be foreign objects blocking the air inlet and/or outlet vents. Remove any obstructing object.
	The purifier may not be switched on. Ensure that the plug is securely connected to a power source and touch the POWER button to switch the purifier on.
Suspicious odors are emitted from the air outlet.	The filter may have reached the end of its lifespan due to heavy pollution. Replace the filter.
The airflow from the air outlet is significantly weaker than before.	The packaging of the filter may not have been removed. Ensure that all the packaging material is removed from the purifier.

## 7. Environment

EN

Name and Content of Hazardous Substances and Elements in Product

Part Name	Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCBA Components	×	○	○	○	○	○
Motor Assembly	○	○	○	○	○	○
Housing	○	○	○	○	○	○
Other Accessories	○	○	○	○	○	○

This table is prepared in accordance with SJ / T 11364.

○ : Indicates that this hazardous substance contained in each of the homogeneous materials for this part is below the limit requirement according to GB/T 26572.

×

X : Indicates that this hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement according to GB/T 26572.



Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.